

## INSTRUCTIONS FOR MOUNTING HERD GT-77 ATV TO CARTON X

1. Assemble seeder as per instruction book.
2. Connect wire with fuse in line to "+" side of battery. Leave the end in place that can easily be reached for connection to seeder.
3. Run a ground from the battery to be connected to the seeder mount.
4. Take the left and right "L" arms and connect the long flat mount bar to the top side of the "L" arms. See photo #1. This must be square when tightened.
5. Connect bottom clamp bar to right "L" angle with bolt and locking nut on top. just start these bolts so this is loose. Slide the mount on the right side as shown in photo #1.
6. Slide so hitch is centered on ATV and connect bottom clamp bar to the left side. Connect the front bolt first, then the rear.
7. Tighten all 4 bolts until they are snug. Do not crush rack.
8. Connect brace rod to left and right side as in photo #2.
9. Mount seeder with two ½" bolts, but do not tighten.
10. Connect brace rods to seeder as in photo #2. Tighten all brace rod bolts and bolts holding seeder to white bar last.
11. Connect wiring and check ground. Seeder is ready to run.

Photo #1



Photo #2

