

# **T700 2" RECEIVER HITCH** **INSTRUCTIONS TO CONNECT M3B TO 2" RECEIVER MOUNT HITCH**



1. Refer to photo to see how hitch is aligned with seeder.
2. Connect bottom of seeder to flat stand with bolt furnished with seeder. **DO NOT TIGHTEN!**
3. Connect top part to mount with furnished bolt and nut. The bolt must be from the inside out. It is important to have the washer on the inside of the tubing of the seeder. Otherwise the tubing may bow out when fully loaded.
4. Tighten all bolts and nuts.
5. It is ready to mount to receiver.
6. **WARNING!!** It is possible you will not have a good ground so a separate ground may be necessary from the seeder to the truck if the motor does not run.