

# Installation Instructions





## Part No. 22798 Pistol Grip Cradle Mount

## Part No. 22799 Joystick Cradle Mount





## Part No. 22815 45° Adapter

## Part No. 22801 & 22844 Floor Mount


### Part No. 22798 Pistol Grip Cradle Mount

			
Remove center phillips head screw to separate Cradle from swivel mount	Attach swivel mount to a suitable location using fasteners provided.	Re-attach Cradle to swivel mount using phillips head screw previously removed.	Insert Pistol Grip Controller into Cradle Mount as pictured above.


### Part No. 22799 Joystick Cradle Mount

			
Remove center phillips head screw to separate Cradle from swivel mount	Attach swivel mount to a suitable location using fasteners provided.	Re-attach Cradle to swivel mount using phillips head screw previously removed.	Insert Joystick Controller into Cradle Mount as pictured above.

### Part No. 22815 45° Adapter



### Floor Mount



Meyer Products LLC assumes no responsibility for installations not made in accordance with these instructions.

Meyer Products LLC reserves the right, under its continuing product improvement program, to change construction or design details, specifications and prices without notice or without incurring any obligation.

Meyer Products LLC  
18513 Euclid Ave. • Cleveland, Ohio 44112-1084  
Phone 486-1313 (Area Code 216)  
email warranty@meyerproducts.com

Meyer New England  
#6 Angell Lane • Damariscotta, ME 04543-9720  
Phone 563-2227 (Area Code 207)  
www.diamondplow.com • email info@diamondplow.com

These products are designed to be used in a safe and secure manner. However, the use of these products may be hazardous if used in an unsafe manner. These products are manufactured in Sweden by a subsidiary of ProClip USA and are not intended for use in vehicles. ProClip products are not intended for use in vehicles or other mobile devices and communication devices including Cell Phones, Mobile Phones, Smart Phones, Photo Cameras, PDA, GPS navigators, PDA MP3 Players, Satellite Radio, Turnkey Radio, Mobile Computers, etc.

**Precautions**

- Some of these products contain small parts that can be a choking hazard for children. Keep out of reach of small children.
- Use caution when operating your communications device when driving.
- By attaching any of the ProClip products to any surface using double-sided tape only, the product may loosen when exposed to extreme heat or cold for longer periods of time.

**Returns**

No products shipped hereunder may be returned without ProClip's prior approval. In order to return a product, buyer must obtain an RMA# (Return Merchandise Authorization Number). All returns must be made within thirty (30) days of the invoice date and include proof of purchase. The product must be in undamaged and unused condition, meaning: NO screw can be screwed into any product, not even into the provided holes; NO holes punched through a product; NO scratches or scuff marks; and NO Velcro use etc. We reserve the right to withhold a refund if we deem the product as damaged. A copy of your original order or invoice must accompany a return. ALL COMPONENTS PERTAINING TO THE ORIGINAL PART MUST BE RETURNED.

**Limited One Year Warranty**

PROCLIP USA, Inc. (PROCLIP USA) warrants that the Products will be free of defects in materials and workmanship for a period of one (1) year from the date of purchase. If any Product should become defective within the warranty period, PROCLIP USA, at its option, will replace it, repair it or refund the purchase price. Repair or replacement parts or Products will be furnished on an exchange basis and will either be new or reconditioned. All replaced Products that become the property of PROCLIP USA. Priority service is available to you by delivering the Product during the warranty period to an authorized PROCLIP USA service facility or to PROCLIP USA at 750 Tower Road, Suite A, Mundelein, IL 60060 USA, and providing proof of purchase price and date. You will bear all shipping, packaging and insurance costs and all other costs, including labor and parts necessary to effectuate repair, replacement or refund under this warranty. For more information on how to obtain warranty service, write or telephone PROCLIP USA at 750 Tower Road, Suite A, Mundelein, IL 60060 USA, Tel: +1 847-888-7171.

THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCT WHICH HAS BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE OR AS A RESULT OF UNAUTHORIZED SERVICE. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES FOR THIS PRODUCT. IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT SHALL HAVE NO DURATION LONGER THAN 1 YEAR FROM THE DATE OF PURCHASE. IN THE EVENT THE PRODUCT BECOMES DEFECTIVE DURING THE WARRANTY PERIOD THE APPLICABLE REMEDY SHALL BE LIMITED TO THE REMEDY BEING OFFERED BY PROCLIP USA.

PROCLIP USA SHALL PROVIDE USA RESIDENCE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION LOSS OF PROPERTY, ARISING FROM BREACH OF ANY EXPRESS OR IMPLIED WARRANTY.

PROCLIP USA shall not be liable for the installation or installation of products or accessories purchased by the user and shall not be responsible for any damage to the user's property or any other damage to the user's property or any other damage to the user's property.