


GT-77 Control Handle #671


Take collar off of end of handle and place in the 2nd hole on GT-77, then replace collar. (See picture 1.)

Picture 1



Place L- bracket on front u-bolt and tighten with 1/4" nut provided.
(See Picture 2)

Picture 2



Handle is now ready to use.

Herd Seeder Co., Inc.
2383 South U. S. 35
Logansport, IN 46947
574-753-6311
www.herdseeder.com